



Turn both nuts to the un-lock position ,  
then pull the bolt head outward.